

U-BOAT
ITALO FONTANA


EN

**DEAR CUSTOMER,
WE CONGRATULATE YOU ON THE PURCHASE OF THIS U-BOAT WATCH.
IN THIS BOOKLET YOU WILL FIND THE INSTRUCTIONS FOR USE, THE
TECHNICAL DETAILS AND THE WARRANTY BOOKLET.
WE KINDLY INVITE YOU TO REGISTER YOUR WATCH
ON OUR OFFICIAL WEB SITE
IN THE U-CLUB AREA, DEDICATED EXCLUSIVELY TO THE U-BOAT WATCHES
OWNERS AND GAIN ACCESS TO FURTHER BENEFITS AND PREVIEWS ON
OUR LATEST NEWS, EVENTS AND OFFERS.**


EMN

WATCH OPERATION INSTRUCTIONS.

- A** SCREW CROWN
- B** HOUR HAND
- C** MINUTE HAND



REPRESENTATIVE IMAGE.



POSITION 1
NEUTRAL POSITION

POSITION 2
FIRST CLICK


INSTRUCTIONS FOR USE.

POSITION 1 Watch operating position.
NEUTRAL POSITION

POSITION 2 Unscrew and pull the crown **A** out to position 2 and turn to adjust time.
FIRST CLICK

Press and screw the crown **A** back to return it to position 1

NB: we advise pulling out crown **A** into position 2 when the watch isn't being used for a long period to limit battery consumption.



BATTERY REPLACEMENT AND OIL ADJUSTMENT

1. Innovative closure system with a compartment for quick battery change. **L**
2. Closing system for oil regulation in the case, exclusively by U-BOAT specialized technicians. **M**

EN

CARE AND MAINTENANCE.

The precision mechanism in your watch will provide long-lasting performance when properly cared for.

We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every year for a check-up, perform ordinary maintenance on all mechanical parts and restore of water-resistance.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap.

Avoid leaving your watch where it is exposed to large temperature variations, humidity, the sun and strong magnetic fields.

Make sure the watch is in adequate conditions for water use/activities.

Remember to rinse the watch after it comes into contact with seawater.

Automatic watches require manual winding following a long period of inactivity.